



Email : sales@samcomedical.com
Phone: 1-300-400-8211

Product Name :
Graticule Magnifier

Product Code :
SAMCOMEDICAL6001A066

Description :

Graticule Magnifier

Technical Specification :

Graticule Magnifier A sophisticated high power stand magnifier with a graticule (reticle) holding attachment. Uses highly corrected precision optics to give fully colour corrected distortion-free and perfectly flat field upto the edge. Has a clear acrylic stand that allows ambient light illumination of object and graticule. Provided with spiral twist mechanism for precision focusing, and a focus lock ring. Ideal for engineering applications like checking small parts, linear measurements, angles, hole diameters, thread size and thickness. With the appropriate graticule it is an invaluable aid as graphic arts comparator for type, spacing and size. Also useful for proof reading and editing, aerial photo checking and geological sand checking. A choice of fifteen different graticules is available for varied applications. The unit is provided with protective moulded case and a dust cover. Magnification : 8x. Field of View : 22mm. Working Distance : 20mm



Samco Medical

Website: www.samcomedical.com,